

# Handle

- |                                    | Fitting group |
|------------------------------------|---------------|
| STRAIGHT H-190 Wood SB<br>No.07995 | A             |
| STRAIGHT H-270 Wood LB<br>No.07990 | B             |
| STRAIGHT H-270 Wood<br>No.15994    | C             |
| STRAIGHT H-300 Wood<br>No.15990    | D             |
| STRAIGHT H-300 Red<br>No.15952     | D             |
| STRAIGHT H-300 Blue<br>No.15953    | D             |
| STRAIGHT H-300 Black<br>No.15971   | D             |
| STRAIGHT H-150<br>No.15958         | D             |
| STRAIGHT H-240 Wood LH<br>No.08990 | E             |
| STRAIGHT H-240 Wood SH<br>No.08992 | E             |
| PISTOL H-126 Yellow<br>No.08993    | E             |
| PISTOL H-126 Blue<br>No.08996      | E             |

- |                                   | Fitting group |
|-----------------------------------|---------------|
| PISTOL H-126 Red<br>No.08991      | E             |
| PISTOL H-126 SH<br>No.15278       | E             |
| STRAIGHT H-330 Wood<br>No.15991   | F             |
| STRAIGHT H-330 Orange<br>No.15973 | F             |

# Combination

◎ recommended ○ possible

Fitting group	A	B	C	D, E	D, E	F
<b>Handle</b>						
<b>Blade</b>						
<b>A</b> DOZUKI FINE150 DOZUKI HARDWOOD150 DOZUKI PIERCING 150 DOZUKI BAMBOO H-150	◎					
<b>B</b> DOZUKI FINE 240 DOZUKI HARDWOOD 240		◎				
<b>C</b> CROSS H-225			◎	○	○	
<b>D</b> CROSS H-250 RIP H-250 UNIVERSAL H-250 HARDWOOD H-250 CROSS H-265 UNIVERSAL H-265 CROSS CONVEX H-265 RIP H-300 BAMBOO H-270			○	◎	◎	○
<b>E</b> PVC 240 SIDING H-120 COPPER 240 UTILITY H-240 TAPERED UTILITY FLUSH H-240 IRON 240 PVC 300			○	◎	◎	○
<b>F</b> UNIVERSAL H-300 CROSS CONVEX H-300 HEAVY DUTY H-333				○	○	◎

⚠ Since the saw teeth are very sharp, we recommend that you wear gloves or wrap the blade with a rag when replacing the blade.

Blade Attachment:



Insert the blade into the holder(spine), and tap the end of the handle to attach the blade.

Blade Detachment:



Tap the end of the handle to loosen the blade and pull the blade out of the holder(spine).